Crank Replacement

What do you need?

- 1. Loctite glue
- 2. Red key
- 3. Spanner
- 4. Socket wrench
- 5. Black cap
- 6. Crank
- 7. Pedal

1.

Unscrew the cap.

2. Place the silver socket wrench on the nut.









Turn the nut loose with the red key. Remove the nut.





4.

3.

Screw the black cap into the crank and secure it with the red key.



5.

Tighten the silver screw in the black cap.

The red key is located between the black cap and silver screw.



6.

Loosen the crank by tightening the silver screw with the red key.



7.

Place the new crank on the Deskbike.

8.

Place the nut.



9.

PAY ATTENTION. Thoroughly clean and degrease the crank screw. Then apply loctite glue and tighten the screw.

Do not give too much force on the screw. Fixed is fixed.

If you give too much force to the screw, you have the chance that it will break off, and then it will be very difficult to repair the Deskbike.



10. Also apply loctite glue on the pedal. 11. Tighten well. 12. Put the cap back. Ready? Do not use the Deskbike for 2 days and allow to dry. wørktrainer